



Palace Wallpaper Mural

Designed by Young and Battaglia, The Palace wallpaper is inspired by the wonderfully opulent interiors of stately homes and palaces of the 18th Century. It features an image of a large hall adorned with beautiful paintings and chandeliers. It can be used to create an illusion of space and grandeur.

Designer: Young & Battaglia

Specification

Dimensions (cm): Made to measure

Drop Length (M): Made to measure

Materials: Fire Rated 300g Textured Vinyl. Commercial Grade.

Important Notes

Due to the printing process, colours may vary slightly between batches. Customers should try to order enough rolls initially, or if re-ordering must provide the Batch number. For help calculating how many rolls are needed please contact us with room dimensions and we can work it out for you! Please also note that images on screen are not a truly accurate representation of print colour.

50CM Wide Textured Paper

Fixing Instructions for Textured Wallpaper

You will need ruler, pencil, scissors, sharp knife, bucket, pasting brush, sponge, plumb line, seam roller and a profile shredder and a level

Adhesive: Use only Solvite Professional and PVA Adhesive

-Mix the wall paste in a 5 litre bucket. Add one pack of Solvite™ extra strong and 4 cup fulls of PVA glue to be mixed well together in bucket. Make sure you follow the instructions on the packet.

-You must ensure that the wall surface that the paper is to be applied is sound and smooth. Any indentations must be taken away at this stage as this would affect pitting on the paper.

-Pre paste the wall area with the PVA and extra strong adhesive ensuring that all surface is covered.

-Place the paper face down on the table.

-Apply the paste to the paper. Make sure it applies evenly to avoid bubbling.

-It is important that you paste up to the edges in an outward motion.

-After pasting paper leave to soak for a period of 5 to 10 minutes

-(Optional) fold a 1/3 of the paper pasted side against pasted side to make it easier to handle.

-Apply the paper to the wall from the top and down using paper hangers brush or profile to smooth out any creases or bubbles.

-Brush outwards all the way down to exclude trapped air.

-Trim the edges of the paper next to doors, radiators etc. using a sharp knife.

-To use a damp sponge or a dry cloth to wipe off any excess PVA from joints, leave then for 24 hours and re-wipe with damp sponge and dry cloth.